

# AQUAFINESSE

- simply clean

## Instructions:

1. Run the garden hose for 60 seconds before filling your whirlpool with fresh water.
2. Mix the solution well by shaking the AquaFinesse bottle. Pour the indicated amount of AquaFinesse into the water. DO NOT use more than recommended amount.
3. Place one (1) cleaner tablet into the float of the supplied slow-release dispenser, close the lid, fill it with water and place it directly into the filter area. Check the dispenser every week to see whether the tablet has fully dissolved.
4. Switch the jets on for two minutes to activate the AquaFinesse water treatment system.
5. Repeat steps 2-4 on a fixed day every week.
6. Clean the filter at least once a week to ensure optimum water care.
7. Check that your ozonator is working properly.
8. Keep a replacement filter to ensure optimum filter cleaning.

## VILLEROY & BOCH

### DEUTSCHLAND

Villeroy & Boch AG  
Unternehmensbereich Bad und Wellness  
Hauptverwaltung  
D-66693 Mettlach

Tel. +49 (0) 68 64-81 15 00  
Fax +49 (0) 68 64-81 14 84

*We have been enhancing domestic life with the finest products for over 250 years. And nobody better understands the physiological and psychological benefits derived from surrounding yourself with high-quality objects that represent an ideal combination of form and function.*

*We have no doubt that Villeroy & Boch sauna/infrared cabins and spa baths will provide years of pleasure and contribute to long-term wellness for you and your family.*



8794 J4 D9 - Shades and dimensions subject to usual tolerances.  
We reserve the right to make technical modifications to the range and alter colours.



Your agent:

  
Villeroy & Boch  
1748

# AQUAFINESSE

Innovative water care for your  
Villeroy & Boch whirlpool.



AQUA FINESSE®



AquaFinesse Watercare System Box



AquaFinesse Filter cleaner tablets



AquaFinesse Perfect Jet



AquaFinesse Spa Clean

## EXPLANATIONS

### **AquaFinesse Watercare System Box:**

This box contains a six-month supply of materials for care of your whirlpool water – two bottles of AquaFinesse solution, a measuring cup and scale, cleaner tablets and an adjustable slow-release dispenser. The small chlorine tablet used in the slow-release dispenser kills all bacteria from the water after they have reached the filter. The amount of chlorine in your whirlpool water is thus reduced to a minimum. It is sufficient, however, to significantly reduce unpleasant odours and drying or bleaching effects that normally occur with chemicals.

### **AquaFinesse Filter cleaner tablets:**

Innovative cleaning for your whirlpool filter. The filter should be cleaned once a month with these tablets, as AquaFinesse functions directly with the filter system.

### **AquaFinesse Perfect Jet:**

The ideal way of keeping your whirlpool filter clean and pure. Perfect Jet cleans your filter more simply than ever before. Perfect Jet is an ideal supplement to the filter cleaner tablets and cleans your filter – and thus your whirlpool – simply, rapidly and above all effectively.

### **AquaFinesse Spa Clean:**

For intensive cleaning of your whirlpool – removes biological and lime deposits.

## AQUAFINESSE

### Crystal-clear water for your whirlpool

Water care without stress – typical for Villeroy & Boch. Take advantage of the simple, time-saving and environmentally sound AquaFinesse water treatment system for your whirlpool.

AquaFinesse is an innovative cleaning system for your whirlpool water that is easy and quick to use.

AquaFinesse makes the water in your whirlpool softer and removes lime deposits. Only a small amount of chlorine – up to 80% less than standard – is used, reducing the risk of skin irritation and allergic reactions to a minimum.

AquaFinesse needs to be used only once a week. The unique formula keeps your whirlpool water clean and pure. The life of your whirlpool is also extended as lime and other harmful deposits are prevented.

